


PXM-MiniPCle

SUMIT-ISM Module with MiniPCle and USB

PRODUCT MANUAL



WinSystems, Inc.
715 Stadium Drive
Arlington, TX 76011

<http://www.winsystems.com>

REVISION HISTORY

P/N 400-0368-000

Date Code	REV Level	ECO Number
100422	A	

Preliminary


TABLE OF CONTENTS

Visual Index - Top View (Connectors)	5
Visual Index - Top View (Jumpers & LEDs)	6
Visual Index - Bottom View (Connectors & Jumpers)	7
Jumper Reference	8
INTRODUCTION	11
FEATURES	11
System.....	11
FUNCTIONALITY	12
MiniPCle Cards.....	12
RF Connectors.....	12
Status Indicators.....	12
User Identity Module (UIM) Connector.....	12
CONNECTOR REFERENCE	13
POWER.....	13
D2 (Power LED +5VSB), D1 (Power LED +5V).....	13
USB.....	13
J8, J9 - USB.....	13
PC/104 BUS INTERFACE.....	14
J16 - PC/104.....	14
SUMIT™ INTERFACE.....	15
J1, J2 - SUMIT.....	15
MiniPCI EXPRESS.....	16
J11 - MiniPCle.....	16
CABLES	17
SOFTWARE DRIVERS & EXAMPLES	18
MECHANICAL DRAWING	19
APPENDIX	20
WARRANTY INFORMATION	21

This page has been left intentionally blank.

Preliminary

Visual Index - Top View (Connectors)



RESERVED - D7, D8

NOTE: The reference line to each component part has been drawn to Pin 1, and is also highlighted with a square, where applicable.

